



# 2001 Maintenance Schedule

ALL MODELS	Miles Kilometers	5	10	20	30	40	50	60	70	80	90	100	105	110	120
		8	16	32	48	64	80	96	112	128	144	160	170	180	192
Engine Oil – change		•	•	•	•	•	•	•	•	•	•	•		•	•
Engine Filter – replace		•	•	•	•	•	•	•	•	•	•	•		•	•
Service Reminder – reset		•	•	•	•	•	•	•	•	•	•	•		•	•
Wheels – rotate		•											a		
Fluid Levels – check		•	•	•	•	•	•	•	•	•	•	•	d	•	•
Auto-Shift Lock – check		•	•	•	•	•	•	•	•	•	•	•	d	•	•
Brake System – check		•	•	•	•	•	•	•	•	•	•	•	i	•	•
Manual Trans – check shift and clutch interlock		•	•	•	•	•	•	•	•	•	•	•	t	•	•
Cooling System – check level			•	•	•	•	•	•	•	•	•	•	i	•	•
Exhaust System – check			•	•	•	•	•	•	•	•	•	•	o	•	•
OBD – check DTC memory			•	•	•	•	•	•	•	•	•	•	n	•	•
Door Hinge Mechanism – lubricate			•	•	•	•	•	•	•	•	•	•	a	•	•
Battery – check level			•	•	•	•	•	•	•	•	•	•	l	•	•
W/W System – check, add fluid			•	•	•	•	•	•	•	•	•	•		•	•
Wheels/Tires/Spare – check condition, pressure			•	•	•	•	•	•	•	•	•	•	s	•	•
Drive Shafts – check boots			•	•	•	•	•	•	•	•	•	•	e	•	•
Road Test			•	•	•	•	•	•	•	•	•	•	r	•	•
Lights – check			•	•	•	•	•	•	•	•	•	•	v	•	•
Engine – check for leaks				•		•		•		•		•	i		•
Front End – check dust seals, ball joints, tie rod ends				•		•		•		•		•	c		•
HalDEX Clutch – change oil & filter*				•		•		•		•		•	e		•
Transmission – check for leaks				•		•		•		•		•			•
Trans Final Drive (man/auto) – check lubricant				•		•		•		•		•			•
				m		m/a		m		m/a		m			m/a
Dust/Pollen Filter – replace				•		•		•		•		•			•
Head Lights – adjust				•		•		•		•		•			•
Sliding Roof – clean, lubricate rails				•		•		•		•		•			•
Power Steering Fluid – check						•				•					•
Air Cleaner – replace element						•				•					•
Spark Plugs – replace						•				•					•
Ribbed Belt – replace										•					
V-Belt – replace**										•					
Timing Belt – replace**															•
Timing Belt – replace***													•		
Timing Belt and Tensioner Roller – replace****													•		
Brake Fluid – replace		every 2 years regardless of mileage													

\*TT quattro    \*\*1.8L Turbo    \*\*\*2.7L V6 and 4.2L V8    \*\*\*\*2.8L V6



## 2002 Maintenance Schedule A6/S6/allroad

	Miles		30		45		60		75		90		105		120		135		150		165	
Kilometers	15	30	45	60	75	90	105	120	135	150	165	180	195	210	225	240	255	270	285	300	315	330
Engine Oil – change	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Engine Oil Filter – replace	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Engine – check for leaks		•		•		•		•		•		•		•		•		•		•		•
Cooling System – check level, add if necessary	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Exhaust System – check for damage, leaks	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Engine OBD – check memory, purge	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Door Hinge Mechanisms – lubricate	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Battery – check electrolyte, add if necessary	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Wiper/Washer – check fluid, add if necessary	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Automatic Shift Lock – check	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Manual Transmission – check shift and interlock	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Tires and Spare – check condition, pressure	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Service Reminder Display – reset	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Brake System – check	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Drive Shaft Boots – check	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Road Test	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Lights – check	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Front Axle – check dust seals, ball joints, tie-rod ends		•		•		•		•		•		•		•		•		•		•		•
Automatic Transmission – check for leaks		•		•		•		•		•		•		•		•		•		•		•
Automatic Transmission Final Drive – check for leaks				•								•										
Manual Transmission – check for leaks		•		•		•		•		•		•		•		•		•		•		•
Manual Transmission Final Drive – check for leaks		•		•		•		•		•		•		•		•		•		•		•
Multitronic™ Transmission – change ATF				•								•										
Power Steering Fluid – check, add if necessary				•								•										
Dust and Pollen Filter – replace		•		•		•		•		•		•		•		•		•		•		•
Headlights – inspect, adjust if necessary		•		•		•		•		•		•		•		•		•		•		•
Sliding Roof – clean, lubricate rails		•		•		•		•		•		•		•		•		•		•		•
Air Cleaner – replace filter element				•								•										
Spark Plugs – replace				•								•										
Ribbed Belt – replace												•										
Ribbed Belt – check**																						•
Timing Belt – replace** ***																						•
Timing Belt and Tensioner Roller – replace*																						•

Brake Fluid – replace every 2 years, regardless of mileage.  
W42AUMAINT2002A4S4A6S6 Printed October 2001

\*2.7L

\*\*3.0L

\*\*\*4.2L



# 2003 Maintenance Schedule

## A4

	Miles	10	20	30	40	50	60	70	80	90	100	105
Kilometers		15	30	45	60	75	90	105	120	135	150	155
Engine Oil – change		•	•	•	•	•	•	•	•	•	•	
Engine Oil Filter – replace		•	•	•	•	•	•	•	•	•	•	
Engine – check for leaks			•		•		•		•		•	
Cooling System – check level, add if necessary		•	•	•	•	•	•	•	•	•	•	
Exhaust System – check for damage, leaks		•	•	•	•	•	•	•	•	•	•	
Engine OBD – check memory, purge		•	•	•	•	•	•	•	•	•	•	
Door Hinge Mechanisms – lubricate		•	•	•	•	•	•	•	•	•	•	
Battery – check electrolyte, add if necessary		•	•	•	•	•	•	•	•	•	•	
Wiper/Washer – check fluid, add if necessary		•	•	•	•	•	•	•	•	•	•	
Automatic Shift Lock – check		•	•	•	•	•	•	•	•	•	•	
Manual Transmission – check shift and interlock		•	•	•	•	•	•	•	•	•	•	
Tires and Spare – check condition, pressure		•	•	•	•	•	•	•	•	•	•	
Service Reminder Display – reset		•	•	•	•	•	•	•	•	•	•	
Brake System – check		•	•	•	•	•	•	•	•	•	•	
Drive Shaft Boots – check		•	•	•	•	•	•	•	•	•	•	
Road Test		•	•	•	•	•	•	•	•	•	•	
Lights – check		•	•	•	•	•	•	•	•	•	•	
Front Axle – check dust seals, ball joints, tie-rod ends			•		•		•		•		•	
Automatic Transmission – check for leaks			•		•		•		•		•	
Automatic Transmission Final Drive – check for leaks					•				•		•	
Manual Transmission – check for leaks			•		•		•		•		•	
Manual Transmission Final Drive – check for leaks			•		•		•		•		•	
Multitronic™ Transmission – change ATF					•				•			
Power Steering Fluid – check, add if necessary					•				•			
Dust and Pollen Filter – replace			•		•		•		•		•	
Headlights – inspect, adjust if necessary			•		•		•		•		•	
Sliding Roof – clean, lubricate rails			•		•		•		•		•	
Air Cleaner – replace filter element, clean screen							•					
Spark Plugs – replace					•				•			
Ribbed Belt – replace									•			
Ribbed Belt – check* **												•
Timing Belt – replace* **												•
Timing Belt and Tensioner Roller – replace***												•

Brake Fluid – replace every 2 years, regardless of mileage.

\*1.8T

\*\*3.0L

\*\*\*2.7L

Cloth top – check rollover function every 2 years, regardless of mileage



# 2004 Maintenance Schedule A6/allroad

	Miles Kilometers	5 8	15 25	25 40	35 55	45 70	55 85	65 100	75 115	85 130	95 145
Engine Oil – change oil and replace filter		•	•	•	•	•	•	•	•	•	•
Wiper/Washer/Headlight washer – check adjust. and function		•	•	•	•	•	•	•	•	•	•
Tires and Spare – check condition, pressure		•	•	•	•	•	•	•	•	•	•
Tires – rotate		•									
Service Reminder Display – reset		•	•	•	•	•	•	•	•	•	•
Road Test		•	•	•	•	•	•	•	•	•	•
Cooling System – check level, add if necessary			•		•		•		•		•
Exhaust System – check for damage, leaks			•		•		•		•		•
Engine OBD – check memory, purge			•		•		•		•		•
Engine – check for leaks			•		•		•		•		•
Battery – check electrolyte, add if necessary			•		•		•		•		•
Dust and Pollen Filter – replace			•		•		•		•		•
Automatic Transmission and Final Drive – check for leaks			•		•		•		•		•
Manual Transmission and Final Drive – check for leaks			•		•		•		•		•
Sunroof – clean, lubricate rails			•		•		•		•		•
Front Axle – check dust seals, ball joints, tie rods, tie rod ends			•		•		•		•		•
Tire Repair Set – check renewal date			•		•		•		•		•
Lights – check			•		•		•		•		•
Headlights – inspect, adjust if necessary			•		•		•		•		•
Brake System – check			•		•		•		•		•
Drive Shaft Boots – check			•		•		•		•		•
Door Hinge Mechanisms – lubricate			•		•		•		•		•
Spark Plugs – replace (except allroad 4.2L)					•				•		
Spark Plugs – replace (allroad 4.2L)							•				
Multitronic™ Transmission – change ATF					•				•		
Power Steering Fluid – check, add if necessary					•				•		
Air Cleaner – clean housing, replace filter element					•				•		
Ribbed Belt – replace (except 3.0)									•		
Ribbed Belt – check (3.0)									•		
Timing Belt – replace (3.0 and 4.2L)									•		
Timing Belt and tensioner – replace (2.7T)									•		

Brake Fluid – replace every 2 years, regardless of mileage